



PNM require that all secondary cables be in duct and all transformer and pedestals shall have service conduit elbows and stub outs installed. Contact your new service representative for assistance.

NOTES

- (1) Install a poly duct plug to both ends to keep out dirt.
- (2) Working clearance is 4' in front of the doors and 1' from the sides.
- (3) To identify duct entrance locations a white vertical tape shall be tied to the end of the stub and brought above the finish ground line.

REFERENCES

- (1) See DS-10-12.0 Secondary Pedestal
- (2) See DS-18-26.0 Overhead and Underground Torque Values

Material List			
Item	Quan.	Description	Stock #
A		3" Conduit Plug	0100-005699
B		3" Diameter, 24" Radius 90° PVC Elbow	7000-462815
C		1 1/2" White Tape	0000-005626
D		3" x 10' Schedule 40 PVC Duct	7000-460560

Single-Phase Pedestal Conduit Orientation