

- A red etched placard on the billing meter that reads "Warning Customer Owned Generation Connected. See drawing for disconnect location."
- One-line and Site Map located within 2' of Billing meters.
- (4) To pass meter set inspection, all generator equipment and breakers must be ready in the ON position, and inverter programmed and ready to operate. PNM cannot access or operated any customer owned equipment except for the meter and utility accessible Generation Disconnect.